USF-HCF

SAFETY ZONE WATER® HIGH CAPACITY UNDER SINK WATER FILTER CONNECTS TO COLD WATER LINE TO FEED FILTERED WATER TO COLD WATER FAUCET (NO DEDICATED FAUCET REQUIRED)

Follow these easy, simple directions:


- Close valve on cold water angle stop valve and open cold water faucet to drain cold water line.
- Install head on filter with screws. (provided).
- Install bracket on side of kitchen cabinet (screws not provided).
- 4. Insert filter cartridge (1/4 turn.)
- 5. Disconnect 3/8" braded hose from cold water angle stop valve.

OUTLET

Disconnect the existing 3/8" braded tubing from the cold water angle stop valve and connect it to the outlet of the filter to feed filtered water from the filter to the faucet.

Components:

- High capacity filter cartridge (10,000 gallons capacity)
- 2. Bracket
- 3. Four mounting screws
- 4. Filter head (quick connect)
- 5. 3/8" stainless braded tubing with compression fittings.



OUT



High Capacity Filter Model: USF-HC-10000

Replacement cartridge: USF-HC-C

Continued . . .

- Connect this hose to the outlet of the filter to feed filtered water to the cold water faucet.
- 7. Connect the filter's 3/8" braded stainless steel hose to the cold water angle stop valve to feed water to the filter.
- Open valve on cold water angle stop valve and open cold water faucet.
- Allow filter to flush until water runs clear.
- 10. Enjoy filtered water.

Note: Hose fittings are 3/8" compression.

Removes / reduces:

- Chlorine
- Harmful chemicals
- Tastes
- Odors.

INLET

IN

Connect the 3/8" tubing attached to the filter to the cold water angle stop valve to feed tap water to the filter.

Part Numbers

Part Number	Description
USF-HC-C	Cartridge
HSF-HC-HEAD	Head
USF-HC-BKT	Bracket

Dimensions (W x L x D): 4.5" x 20" x 4.5"



www.safetyzonewater.com